



- 1) Button
- 2) Fixing part
- 3) Lighting tunnel
- 4) Frame
- 5) Base
- 6) Screw of the claw
- 7) Tumbler



The position of the switch for fluorescent lamps and compact fluorescent lamps.

The position of the switch for incandescent lamps, halogen lamps and low – voltage halogen lamps.



Technical Features:

- Single-pole, double- way 10AX 250V-switch.
- 5mA, blue light and a life-span of 100.000 hours (~11 years) (LEDs).
- LEDs that can operate together with incandescent lamps, halogen lamps and low – voltage halogen lamps.

Assembly:

- 1- The position of the switch on the back cover should be selected, depending on the type of light the switch will control as shown in the connection diagram.
- When incandescent lamps, halogen lamps and low – voltage halogen lamps

are used, the position of the switch must be "ON" if you wish the LEDs to light up and in "OFF" position if you do not wish them to light up.

- The LEDs, turn on and off independently according to the position of each switch.

- When fluorescent lamps and compact fluorescent lamps are used, the position of the switch must be turned to "OFF" and the LEDs should be off, otherwise the LEDs will cause the lamps to operate inappropriately.

- 2- The cable connections should be done as shown in the connection

diagram. Place the base (5) in the mounting box and tighten the screws on the claw (6) with an appropriate screwdriver.

- 3- Place the fixing part (2) to the frame (4). Lighting tunnels (3) should be put in the slot on the side of the frame.

- 4- Put the frame on the base and fix the frame to the base by pressing on the lighting tunnels as shown in the figure (9).

- 5- The assembly is completed after the pins inside the button (1) are pushed into the slots on the tumbler (7).